

VSP-03 Visible Pen - Laser Diode


Description:


The Visible Pen is used to check or identify singlemode and multimode optical fibers & components. The universal adapter is suitable for every 2.5 mm or 1.25 mm fiber optic connector. The small, compact and handy housing makes the device suitable for daily use.

Specification:

Wavelength		630 - 680 nm	
Output power singlemode		≥ 0.3 mW	
multimode		≥ 1.0 mW	
Distance		up to 5 km	
Operation Mode		CW, Pulse, ON/OFF	
Laser Class		3R	
Dimensions length		168 ± 2 mm	
diameter		13.5 mm	
Batteries		Alkaline AAA, 2 pcs	
Suitable fiber optic connectors	VSP-03-250	E2000, FC, SC, ST, LSA,	standard 2.5 mm ferrule
	VSP-03-125	LC, MU, LX5,	SFF 1.25 mm ferrule
Operating Temperature		-10°C to +50°C	
Storage Temperature		-40°C to +70°C	

Operating Instruction:





Inserting the batteries:

Unscrew the cover and insert batteries (3) with the correct polarity. The correct polarity is shown in the drawing.

Operation

The instrument can be switched on and off by pressing the button (1). By repeatedly pressing the button (4) the operator can select between a continuous light mode, flashing mode with approximatelly frequenzy 3 Hz and ON/OFF mode. Signalization LED (2) shows the selected mode. Then the laser beam will emerge from the outlet.

Ordering Code:





Never look into the laser beam and do not point it at humans or animals. Laser radiation can cause damage to the eyes or skin. Do not point the laser pointer at a mirror or other reflecting surfaces. The uncontrolledly deflected beam can hit humans or animals. The device and the batteries are not for children. They are not a toy. The product is equipped with a class 3R laser product.



OPTOKON, a.s. Other names and trademarks mentioned herein may be the trademarks of their respective owners. OPTOKON, a.s. reserves the right to make changes, without notice, to the products described in this document, in the interest of improving design, operational function and/or reliability. OPTOKON, a.s., Cerveny Kriz 250, 586 01 Jihlava, Czech Republic tel. +420 564 040 111, fax +420 564 040 134, WWW.OPTOKON.COM, INFO@OPTOKON.CZ